

BAUER COMPRESSOR MAINTENANCE GUIDELINES

Bauer provides complete maintenance guidelines in their operators manual.

Please review and adhere to these guidelines for your specific machine.

Listed below are some general guidelines that you need to be aware of:

- 1) Bauer recommends operating the compressor for a minimum of 30 minutes once per week to maintain lubrication on the first stage valves and to minimize corrosion.
- 2) Bauer recommends changing the synthetic compressor oil every 1,000 hours or once per year, whichever comes first.
- 3) Bauer recommends rotating the air filter element one-quarter (1/4) turn every three (3) months, and the air filter should be replaced every 1,000 hours or once per year, whichever comes first.
- 4) Bauer recommends replacing the oil filter every 1,000 hours or once per year, whichever comes first.
- 5) Bauer recommends changing the air purification cartridge at the end of its design life, or once per year.

SUPPLIERS TO THE FIRE AND RESCUE MARKETS

